

# LinerLife™

## LinerLife Installation Instructions

For best results, unfold the LinerLife liner pad 24 hrs prior to installation to allow crease lines to smooth out.

1. After the pool wall has been assembled, smooth and level the appropriate amount of sand on the pool floor. Sand covers should be created at this time as well.

**NOTE:** If foam covers are being used, install after the pad has been put down.

2. Spread the precut pool liner over the sand, ensuring it is even around the perimeter of the pool.
3. If a foam cove is being used, install it over the liner pad (as shown in illustration right).
4. Install the liner over the liner pad and foam cove (if applicable).

